




WIRING THE **BELTROL** **AL-5r** ESC.




Three wire cable.
Ensure plugs are
correctly located.

Ensure plugs are correctly located.
Orange wire towards middle of RX.

Please see the sound system brand specific
instructions for how to wire a sound system.
http://www.beltrol-rc.com/index.php?page_id=1332



WIRING THE **BELTROL** **AL-6r ESC.**



Three wire cable.
Ensure plugs are
correctly located.

Ensure plugs are correctly located.
Orange wire towards middle of RX.

Please see the sound system brand specific
instructions for how to wire a sound system.
http://www.beltrol-rc.com/index.php?page_id=1332

