


WIRING THE *RCS - BELTROL*

ECL-PnP5 ESC with AristoCraft® PnP sockets using Track Power or batteries in a trail car. Set TRACK - BATTERY switch to suit.

PLEASE NOTE:

**SPEKTRUM® R/C & PLANET TWISTER® R/C ARE GROUP "A" SYSTEMS.
HOBBY KING® R/C & E-SKY® R/C ARE GROUP "B" SYSTEMS.**



CAUTION:


**GROUP "A" R/C SYSTEMS MUST USE THE BTL2vA1 PROGRAM.
GROUP "B" R/C SYSTEMS MUST USE THE BTL2vB1 PROGRAM.**

WIRING THE *RCS* - *BELTROL*

ECL-PnP5 ESC with **BACHMANN PnP** sockets using **Track Power** or **batteries** in a trail car. **Default direction is incorrect. To change it, use the programming options. See instructions.**

PLEASE NOTE:

SPEKTRUM® R/C & PLANET TWISTER® R/C ARE GROUP "A" SYSTEMS.
HOBBY KING® R/C & E-SKY® R/C ARE GROUP "B" SYSTEMS.



CAUTION:

GROUP "A" R/C SYSTEMS MUST USE THE **BTL2vA1** PROGRAM.
GROUP "B" R/C SYSTEMS MUST USE THE **BTL2vB1** PROGRAM.