


# WIRING THE **BELTROL** **AL-3r ESC.**



Three wire cable.  
Ensure plugs are  
correctly located.

Ensure plugs are correctly located.  
Orange wire towards middle of RX.

Please see the sound system brand specific  
instructions for how to wire a sound system.  
[http://www.beltrol-rc.com/index.php?page\\_id=1332](http://www.beltrol-rc.com/index.php?page_id=1332)



FUSE. We suggest you use a  
# RUE-300 3 amp Auto reset Polyswitch.  
NOT required with BIK-U3/6.

