



PO BOX 1118 BAYSWATER, VIC 3153, AUSTRALIA  
 PHONE: INTERNATIONAL ++614 2902 9083  
 AUSTRALIA (04) 2902 9083 VOIP via Engin®  
 Web: <http://www.rcs-rc.com> Email: [rcs@rcs-rc.com](mailto:rcs@rcs-rc.com)

# RCS # BIK-TC5/10.

DIY INSTALLATION KIT FOR TRAIL CARS

Use this battery installation kit with any R/C. It comes in 5 amp & 10 amp versions. It comprises the following components:  
 1 x PCB with ON-OFF switch, charge jack, fuse, rf chokes, screw terminals and an LED power ON indicator.  
 1 x Two way AC compatible cable w/In-line connector for trail car to Loco connection. Connector hook on loco side.  
 4 x pieces of system hook up wire.

You will need a small soldering iron, resin core solder and some heatshrink tubing to insulate solder joints. If you anticipate using regular twin stick NiCd or NiMh battery packs with Tamiya type connectors on each pack you can also purchase the #Y-CABLE which will put 2 x Twin Stick battery packs in series. **INSTALLATION.**

1. Place the BIK-TC5/10 in any suitable location such as a box car door. You can mount with double stick tape or a good quality silicone adhesive. Do not allow metal objects to touch the rear of the PCB. Damage to PCB may result.
2. Follow the wiring diagram carefully. As various brands of locos are wired differently we cannot offer "One Size Fits All" instructions. It is essential the loco track pick ups be disabled otherwise throttle output voltage will be transferred to track & cause all sorts of problems. The antenna wire should be kept as high as possible.

