


# WIRING THE *RCS-BELTROL*

**BTL-PnP5 ESC with AristoCraft® PnP sockets using Track Power **AND** battery back up. Set TRACK - BATTERY switch to TRACK only.**

## PLEASE NOTE:

**SPEKTRUM® R/C & PLANET TWISTER® R/C ARE GROUP "A" SYSTEMS.  
HOBBY KING® R/C & E-SKY® R/C ARE GROUP "B" SYSTEMS.**



## CAUTION:

**GROUP "A" R/C SYSTEMS MUST USE THE BTLvA2 PROGRAM.  
GROUP "B" R/C SYSTEMS MUST USE THE BTLvB2 PROGRAM.**

# WIRING THE *RCS-BELTROL*

**BTL-PnP5 ESC with BACHMANN PnP sockets using Track Power **AND** battery back up.**


**Default direction is correct as shown.**

**Set TRACK - BATTERY switch to TRACK only.**

## PLEASE NOTE:

**SPEKTRUM® R/C & PLANET TWISTER® R/C ARE GROUP "A" SYSTEMS.**

**HOBBY KING® R/C & E-SKY® R/C ARE GROUP "B" SYSTEMS.**



## CAUTION:


**GROUP "A" R/C SYSTEMS MUST USE THE BTLvA2 PROGRAM.**  
**GROUP "B" R/C SYSTEMS MUST USE THE BTLvB2 PROGRAM.**

# WIRING THE *RCS-BELTROL*

**BTL-PnP5 ESC with BACHMANN PnP sockets**  
using Track Power **AND** battery back up

with a #BIK-K27 kit.

Set TRACK - BATTERY switch to TRACK only.




**CAUTION:**

GROUP "A" R/C SYSTEMS MUST USE THE **BTLvA2** PROGRAM.  
GROUP "B" R/C SYSTEMS MUST USE THE **BTLvB2** PROGRAM.

# WIRING THE *RCS-BELTROL*

**BTL-PnP5 ESC with BACHMANN PnP sockets using Track Power **AND** battery back up with a #U-BIK kit.**

**Set TRACK - BATTERY switch to TRACK only.**



## CAUTION:

GROUP "A" R/C SYSTEMS MUST USE THE BTLvA2 PROGRAM.  
GROUP "B" R/C SYSTEMS MUST USE THE BTLvB2 PROGRAM.